

TO LOCATE SKI CENTER:

- 1) PRINT, CUT ENDS OF SHEET & CUT FROM SIDES TO EXTENT OF LINE SHOWN
- 2) ROUGHLY PLACE PRE-TAPED PAPER ON APPROXIMATE SKI CENTER
- 3) ADJUST TOP OF SHEET UNTIL THE SAME COLOR (1MM APART) AND LETTER MATCH ON EACH EDGE
- 4) CREASE AT EDGES AND ROLL DOWN ONE PIECE OF TAPE
- 5) REPEAT PROCESS AT BOTTOM & ROLL DOWN OTHER TWO PIECES OF TAPE
- 6) MARK CENTER LINE ON SKI
- 7) EITHER REMOVE AND EXTEND LINE ON SKI OR LEAVE ON
- 8) PLACE PAPER BINDING TEMPLATE OVER THIS PAGE OR ON SKI AND ALIGN CENTERS.
- 9) MARK DRILL POINTS WITH SHARP AWL AND DRILL AS REQUIRED TO APPROPRIATE DEPTH



© SlideWright.com

We are providing these techniques and recommendations as an assistance and accept no responsibility for this or other maintenance and repair tasks and risks taken on by those willing to carefully keep their gear in top shape and prolong useful life. © 2008 SlideWright.com & TMA Associates expressly reserves the common law copyright & other property rights in these ideas, comments, images, & drawings, etc. These ideas, comments, images, and drawings, etc, whether explicitly copyrighted or not, are not to be changed, copied or linked to in any manner whatsoever, nor are they to be assigned to any third party without first obtaining documented consent from SlideWright.com & TMA Associates.

